



Thank you for have chosen one of our armboards.

How to install the armboard for Systemdek II turntables.

Step Nr 1

Remove the existing board, the existing M5 screws will be used to fix the new board.

Step Nr 2

Mount your tonearm on the armboard following the manufacturer's instruction, if you purchased an armboard for Rega 3-points tonearms or SME tonearms, then you need to use the self-tapping screws supplied to fix your tonearm on the board; the holes are already tapped, but anyway, the provided screws are still a tight fit, use care installing these screws. If you purchased a board for older Rega with captive nut mounting, you will find few MDF spacers to put between the board and the nut.

Step Nr 3

The board is supplied with 1 MDF spacer. The spacer is 3mm thick, put the two M5 screws in the armboard's holes for guidance and then peel off the protective tape of the adhesive pads, and then stick the spacer to the board.

The Vinyl Source

Step Nr 4

Mount the new board in place using the two original M5 screws, do not tighten the screw too much, perspex is hard and fragile and can crack if too much tension is applied on the board.



The mounting holes on the board are symmetric, this means that the board can be mounted either ways, while the tonearm's mounting hole can't. For reference use the 'The Vinyl Source' logo engraved on the board to spot the right way to mount your board (see picture).

If you are not satisfied, you can return this board with all the accessories to:

The Vinyl Source Ltd

80 Etime Street Wishaw ML2 0NT

within 30 days from the date of purchase.

The Vinyl Source Ltd
Registered office:
71-75, Shelton Street, London WC2H 9JQ