

The Vinyl Source

Thank you for have chosen one of our armboards.

How to install the SME armboard for Thorens TD145 / TD146 / TD147 / TD160 TD165 and TD166

1. Remove the existing board and the pillars that might come with it.
2. Put the board on the turntable with the three M3 holes in correspondence of the mounting holes left empty from the old board
3. Look if the cut on the board does not show any metal part of the turntable's chassis if so mark the region and then shave the metal off with a Dremel.
4. Check if the old board mounting holes are large enough to accept the M3 standoff spacers supplied with the board if they are too small use a 3mm drill bit to enlarge the holes.
5. Install the supplied standoff hex spacers in the three holes left free from the previous board.
6. Mount the new board in place using the 3 M3 Allen screws supplied, do not tighten the screw too much, perspex is hard and fragile and can crack if too much tension is applied on the board.
7. Install your SME arm, the four holes are already tapped, but anyway, the four supplied screws are still a tight fit, use care installing these screws.
8. In your SME arm there are four rubber grommets around the mounting screws, take care that these grommets won't be squeezed, the screw must be mounted so that the grommet retain elasticity and the board and slightly move within the flexibility of the grommet.

If you are not satisfied, you can return this board with all the accessories to:

The Vinyl Source Ltd
% Marco Mazzocchi
80 Eive Street
Wishaw
ML2 0NT

within 14 days from the date of purchase.

The Vinyl Source Ltd
Registered office:
71-75, Shelton Street, London WC2H 9JQ